

Quick Start User Guide

XMS-110



Contents



Barco N.V.
Beneluxpark 21 8500 Kortrijk (Belgium)

Registered Office:
Barco N.V.
Pres. Kennedypark 35
8500 Kortrijk (Belgium)
RPR Kortrijk - BE0473191041

1

Standard mounting options

For additional mounting
options check !




or



Horizontal setup

Bottom view



<https://www.barco.com/en/product/xms-110/>


1

Continued...


Vertical stand (optional)

Side view

①



②



page intentionally left blank

2

Connecting the display (optional)

Rear view



DisplayPort output ports

3

Connecting audio (optional)

Rear view



Line in
Mic in
Rear out

Line out
Headphone
S/PDIF

11

Additional mounting options (optional)



Mounting on top

Side view



Mounting below

Side view



9

Configuring the appliance

1



Email: admin@yourcompany.com

Password: admin

2

I have read and accept the EULA

Collaboration Management Suite Version 01.05.00. (138)

Log in to Collaboration Management Suite

Email: admin@yourcompany.com

Password: *****

☐ Remember me

☒ I have read and accept the EULA

Follow the instructions on screen to configure your Barco Collaboration Management Suite!



Check User Manual for detailed information!

Personalization Registration System settings Network settings Overview

Personalization

Locale: English

Device Name

Provide a device name that allows you to easily identify the device.

Serial number: 423E53AA 4ED9 96A1 CCA3

Collaboration Management Suite Version 01.05.00. (138) IT Admin

Control panel

Base Units

Scheduler

Personalization

Network

Security

System

Support & updates

What do you want to do today ?

Collaboration Management Suite

Version: 01.05.00. (138)
IP address: 10.51.40.171
Hostname: h3340ceb5a8a


Users

1 active user(s)

4

Connecting keyboard and mouse (optional)

Rear view




USB 2.0

5

Connecting to network

Rear view



LAN cable

6

Connecting external power supply unit

Rear view



power cable

Power rating:
100-240V~,
2 A, 50-60 Hz



DC in

7

Switching on

Front view



Power button

8

Finding IP address

